



Gpstracker.net.in

Freedom is lost now...!

PREMIUM-pv1

Thanks for purchasing of mp1 and we allotted an account in premium server with 100 sms credits
Please follow the procedure in step wise manner.

Step:1 gprs sim activation

Take gprs activated sim with balance of rs 20 inr atleast(to know gprs activated or not install the sim in mobile and open www.google.com if google site is loaded then gprs is active if site does not load contact gprs service provider. Tracker uses only 30mb/month

Recommended gprs service - airtel gprs -128/month(online recharge offer)
-aircel gprs-47/month

Step: 2- Switching on pv1 model.

Insert simcard and switch on the switch then you can see the red light

Then call the phone number of sim, you should hear 4 rings and auto disconnected and your will be auto answered if mic connected default

Step3:quick setup

From your mobile please send sms.

1.For apn settings for example with airtel sim card

APN123456(SPACE)aircelgprs

You get reply as APN OK

2.for admin ip settings

adminip 123456(space)37.59.232.31(space)10200

you will get reply as adminip ok

3.for gprs mode realtime tracking

GPRS123456

You will get reply as gprs ok

4.time interval upload

T010s*n123456**

You will get replay as tn ok

Other settings

STEP-4: for live tracking

Place the device in open sky.

Then open <http://www.gpstracker.net.in/gs>

User name: your mail id

Password: 123456



Gpstracker.net.in

Freedom is lost now...!

then you can able to see your device live and track them now.

Note:1. to know **additional features** of server plz click on this link.

<http://www.gpstracker.net.in/premiumserversupport.html>

2.for full complete **instruction manual** download from below link <http://gpstracker.net.in/download/pv1.doc>

3.Download **desktop application** from <http://www.gpstracker.net.in/download/pwebtrack.rar>

If you have any more queries regarding installation please can call us on 09700025002 or 040 64559002 or mail us at contactus@gpstracker.net.in

